



OptiSPICE

The First Opto-Electronic Circuit
Design Software

5.0

New Features

OptiSPICE is the first circuit design software for analysis of integrated circuits including interactions of optical and electronic components. It allows for the design and simulation of opto-electronic circuits at the transistor level, from laser drivers to transimpedance amplifiers, optical interconnects and electronic equalizers.



Key Features for OptiSPICE 5.0

OptiSPICE 5.0 introduces new electrical models for characterizing hetero-structure bipolar transistors (Mextram and Agilent), a physical model for spiral inductors (for Si and III-V based substrates), and a new Waveguide Crossing device.

New HBT models for BJTs

Further to the Integral charge control model of Gummel and Poon, new models have been added to the bipolar junction transistor (BJT) model, including the Mextram 504 model¹ for Si/SiGe devices and the Agilent HBT model² for III-V based materials.

Designers will now be able to accurately characterize the performance of HBT-based, high speed (>10 GB/s) BJT configurations for laser and modulator current drivers and receiver amplifier designs.




Fig 1: Example sweep plots (I_c as a function of V_{ce} for different base currents) for the Mextram common emitter configuration.

For the Mextram 504 model in a BJT simulation (with model name “mextram”), use the following (for NPN and PNP BJT configurations):

```
.model mextram NPN level = 504 <param1=val1> <param2=val2>...
```

```
.model mextram PNP level = 504 <param1=val1> <param2=val2>...
```

¹<http://www.nxp.com/models/simkit/bipolar-models/mextram.html>

²http://cp.literature.agilent.com/litweb/pdf/ads2008/ccnld/ads2008/AgilentHBT_Model_%28Agilent_Heterojunction_Bipolar_Transistor_Model%29.html

For the Agilent HBT model in a BJT simulation (with model name “agilent”), use the following (for NPN and PNP BJT configurations):

```
.model agilent NPN level = 101 <param1=val1> <param2=val2>...
```

```
.model agilent PNP level = 101 <param1=val1> <param2=val2>...
```




Fig 2: BJT (Mextram) Common Emitter configuration.

New physical model for Spiral Inductors

A new physically-based inductor model is now available for the Inductor element. The Inductor Model utilizes a lumped circuit approach (Fig 3) to model the electrical characteristics of a spiral inductor³. Mathematical methods for calculating the inductance (L_s) of square, hexagonal, octagonal, and circular planar inductors are also included. These methods include the Modified Wheeler, Current Sheet and Monomial expressions.

The Inductor model works for both Si and III-V based substrates.

Example Netlist format

An Inductor L1 with model name "SiInductorModel" and a line-width of 29.7e-6, is defined as follows:

```
L1 1 0 SiInductorModel
```

```
.model SiInductorModel IntInd w = 29.7e-6
```




Fig 3: OptiSPICE 5.0 Lumped Circuit model for Spiral Inductors.

³ S.S. Mohan, M.M Hershenson, S.P. Boyd, and T.H. Lee, Simple Accurate Expressions for Planar Spiral Inductances, IEEE Journal of Solid-State Circuits, Vol. 34, No. 10, October 1999

New waveguide crossing device

The *Waveguide Crossing* device simulates the transmission and reflection effects that occur when two waveguides cross. This new device is useful for the design and performance analysis of integrated photonics circuits for on-chip optical interconnect and switches (such as micro-ring based routing elements).

The waveguide crossing device is based on the XCOUPLER model (the *ElemType* must be set to WGUIDECROSS to enable the model for this type of application).

Example Netlist format

For a waveguide with device name WC1 connected to signals SIG1, SIG2, SIG3 and SIG4 and with a through port transmission of = 0.7, a right port transmission of 0.1, a left port transmission of 0.1 and a return reflection of 0.1, the Netlist statement to be generated as follows:

```
Osp XCOUPLER Name=WC1 Nodes= [SIG1 SIG2 SIG3 SIG4] MoName=WC_MODEL
```

```
+ Through=0.7 Right=0.1 Left=0.1 Ref=0.1
```

```
Osp Model Name = WC_MODEL type = XCOUPLER ElemType=WGUIDECROSS
```




Fig 4: New waveguide crossing component.